



NOTE:

There might be a plastic smell coming from the air fryer during the first few uses. This is normal and in no way harmful. To get rid of the plastic smell, you can run a 30-minute cycle with an empty basket at the highest temperature.

For customer service questions or comments
visit us at gourmia.com
email info@gourmia.com

or call **888.552.0033**

Support Hours: Mon-Thu 9:00am to 6:00pm EST
Fri 9:00am to 3:00pm EST

Languages Supported: English, Spanish, and French